
Readme / Installation instructions OSCOPE V6.60 Hotfix 7

Modifications

The following modifications have been implemented with **OSCOPE V6.60 Hotfix 7**:

- Remote Communication Dakon-Simeas R
- Faultlocator 3-phase shows the correct fault location in the Overview of the Oscope P Content list
- The Vector diagram shows the vectors in the correct length of their amplitude

Notice!

- **OSCOPE V6.60 Hotfix 7** may only be copied to an existing **OSCOPE V6.60 Installation with or without** Hotfix 1, 2, 3,4,5 or 6. Hotfix 7 includes all changes implemented in Hotfix 1 to Hotfix 6.
- **OSCOPE V6.60 Hotfix 7** may only be used if the Windows XP operating system with SP2 or SP3 has been installed.

Contents of the Consignment

The **OSCOPE_P_V6_60_Hotfix_7.zip** file includes the following individual files and subdirectories:

- dlng1lib.dll
- dlng2lib.dll
- elng1lib.dll
- elng2lib.dll
- flng1lib.dll
- flng2lib.dll
- ilng1lib.dll
- ilng2lib.dll
- os_dat.dll
- os_dll.dll
- os_sys.dll
- osc16ole.dll
- osdatqb.dll
- osimpexp.dll
- ospar.exe
- p600rslt.dll
- qrresult.dll
- sercomm.dll
- siceval.exe
- slng1lib.dll
- slng2lib.dll
- srv4para.dll
- vdewcomm.dll
- ReadMe_OSCOPE_P_V6.60_HF7_de.pdf
- ReadMe_OSCOPE_P_V6.60_HF7_en.pdf
- \binui\ (...)
- \manuals\ (...)
- FP600txt.txt

-
- IP600txt.txt
 - SP600txt.txt

Installation

Terminate all running **OSCOPE V6.60** applications.

- Copy the **OSCOPE_P_V6_60_Hotfix_7.zip** file into the **OSCOPE V6.60** directory[..\Siemens\OSCOPE] and unzip it in this directory. Select all files in the internal **OSCOPE_P_V6_60_Hotfix_7\OSCOPE_660_HF7** folder and copy them into the [...\Siemens\OSCOPE] root directory. Confirm the message that you really want to replace the existing files.

Note

- With the default installation, **OSCOPE V6.60** is located in drive [C:], [..\Siemens\OSCOPE] directory.
- If you do not know the storage path of **OSCOPE V6.60**, open the [win.ini] file in the [Windows] directory, e. g. [C:\WINNT\win.ini], and search the [OSCOPE P] entry in this file. Below this entry, the path of **OSCOPE V6.60** is indicated in this value **Path=Ihr_OSCOPE_P_V6.60_Path**.

Commissioning

Start your **OSCOPE V6.60** applications as usual.